

User manual

Bruksanvisning

Brugsanvisning

Käyttöopas



Cylinda
år efter år

INSTRUCTIONS FOR USE

EN

DESCRIPTION AND USE

DIAGRAM OF THE APPLIANCE (Fig. 1)

1. Lid handle.
2. Lock (if provided).
3. Seal.
4. Defrost water drain plug (depending on model).
5. Control panel.
6. Basket (depending on model).
7. Condenser (located at the rear).

INSTALLATION

- Refer to chapter “Before using the appliance”.
- Unpack the appliance.
- Remove the 4 protection pieces inserted between lid and appliance (Fig 3).
- **Warning: two of the four protection pieces must be fitted in the seat of the condenser plastic supports, located at the rear of the product (Fig. 3).**

This is necessary to ensure the correct distance from the wall.

- Ensure that the defrosting water drainage plug (if provided) is correctly positioned (4).
- For best operation of the appliance and in order to avoid damage when the lid is opened, leave a space of at least 7 cm from the rear wall and 7 cm at the sides.
- Fit the accessories (if provided).

Clean the inside of the appliance before using it.

DIAGRAM OF THE CONTROL PANEL (Fig. 2)

a. Red LED: when flashing, it indicates that an alarm condition is present see TROUBLESHOOTING GUIDE"

b. Green LEDs: they indicate that the appliance is in operation, and the temperature has been set as follows:
b1 less cold temperature (right light on), use this setting with partial loads will optimize energy consumption.
b2 middle temperature (center light on)
b3 very cold temperature (left light on)

ALL Green LEDs ON: FAST FREEZING function is active; see the section “freezing fresh food”.

C. Temperature setting button: to adjust the set temperature and to activate/deactivate the fast freezing operations.

To select the desired temperature, repeatedly press the setting button (3): each time the button is pressed, the set temperature is updated.

To activate/deactivate fast freezing function, pressing for approximately 3 seconds: all green LEDs flash simultaneously 3 times and then remain lit.

Note:

The settings will be saved in the memory even if a power cut occurs. The time needed for the temperature inside the freezer to reach the set value, can vary depending on climatic conditions and the set temperature itself.

Switching on the appliance

- Plug in the appliance.
- The green LED lights up (middle temperature).
- The red LED flashes to indicate that the temperature inside the appliance is not yet sufficiently low for food storage. The red LED will normally switch off within the first six hours after the appliance is switched on.
- Place food inside the product only when the red LED has switched off.

Note:

As the seal is tight, the appliance lid cannot be reopened immediately after closing. Wait a few minutes before reopening the lid of the appliance.

FREEZING FOOD

Preparation of fresh food for freezing

- Before freezing, wrap and seal fresh food in: Aluminium foil, cling film, air and water-tight plastic bags, polyethylene containers with lids, provided they are suitable for freezing foods.
- Food must be fresh, mature and of prime quality in order to obtain high quality frozen food.
- Fresh vegetables and fruit should preferably be frozen as soon as they are picked to maintain the full original nutritional value, consistency, colour and flavour.
- Always leave hot food to cool before placing in the appliance.

Freezing fresh food

- Place foods to be frozen in direct contact with the walls of appliance (Fig. 4)
A) - foods to be frozen,
B) - foods already frozen.
- Avoid placing foods to be frozen in direct contact with food already frozen.
- For best and fastest freezing, foods should be split into small portions; this will also be useful when the frozen items are to be used.

1. At least 24 hours before storing fresh foods inside the product for freezing, activate the fast freezing function by

INSTRUCTIONS FOR USE

pressing button **C** for approximately 3 seconds. All green LEDs (**b**) comes on.

2. Introduce the food to freeze inside the appliance, and keep the door of the appliance closed for 24 hours. After this period the food will be frozen. The fast freezing

function can be deactivated pressing button **C** for approximately 3 seconds.

If the fast freeze function is not manually deactivated, it will be automatically deactivated by the appliance after 50 hours.

FOOD STORAGE

Refer to the table on the appliance.

Classification of frozen foods

Put the frozen products into the appliance and classify them; the storage date should be indicated on the packs, to allow use within expiry dates listed in months in **Fig. 5** for each type of food.

Advice for storing frozen food

When purchasing frozen food products:

• Ensure that the packaging is not damaged (frozen food in damaged packaging may have deteriorated). If the package is swollen or has damp patches, it may not have been stored under optimal conditions and defrosting may have already begun.

• When shopping, leave frozen food purchases until last and transport the products in a thermally insulated cool bag.

• Once at home, place the frozen foods immediately in the appliance.

• Avoid, or reduce temperature variations to the minimum. Respect the best-before date on the package.

• Always observe the storage information on the package.

Note:

Eat fully or partially defrosted foods immediately.

Do not refreeze unless the food is cooked after it has thawed. Once cooked, the thawed food can be refrozen.

If there is a long power failure:

• **Do not open the appliance lid except to place ice packs (if provided) over the frozen foods on the right and left of the appliance. This will slow down the rise in temperature.**

DEFROSTING THE APPLIANCE

The appliance should be defrosted when the thickness of ice on the walls reaches 5-6 mm.

• Disconnect the appliance from the mains power supply.

• Remove the packs of food from the appliance and wrap them close together in newspaper and store in a very cool place or thermally insulated bag.

• Leave the appliance lid open.

• Remove the internal defrost water drain plug (depending on model) (**Fig. 6**)

• Remove the external defrost water drain plug (depending on model) and reposition it as shown in the **figure 6**.

• Place a bowl beneath the drainage channel to collect the residual water. If available, use the divider (**Fig. 6**)

• Speed up defrosting by using a spatula to detach the ice from the appliance walls.

• Remove the ice from the bottom of the appliance.

• In order to avoid permanent damage to the appliance interior, do not use pointed or sharp metal instruments for removing the ice.

• Do not use abrasive products or heat up the interior artificially.

• Dry the interior of the appliance thoroughly.

• On completion of the defrosting, refit the plug.

CARE AND MAINTENANCE

• Remove the ice from the upper edge (see the Troubleshooting Guide).

• Clean the inside after defrosting, using a sponge dampened with warm water and/or mild detergent.

• Clean the side motor cooling grille (depending on model).

• Remove dust from the condenser on the rear of the appliance.

Before carrying out maintenance, unplug the appliance.

Do not use abrasive products, scourers or stain-removers (e.g. acetone, trichloroethylene) to clean the appliance.

To obtain the best results from your appliance, carry out cleaning and maintenance at least once a year.

CHANGING THE LID LIGHT BULB (if provided)

• Disconnect the appliance from the mains power supply.

• Remove the diffuser by following the sequence of steps shown in the **figure 7**.

• Unscrew the light bulb and replace it with an identical bulb of the same wattage and voltage.

• Refit the diffuser and plug in the appliance.

TROUBLESHOOTING GUIDE

1. The red LED flashes.

• Is there a power failure?

• Is a defrosting operation in progress?

• Is the appliance lid properly closed?

• Is the appliance placed near a heat source?

• Are the ventilation grille and condenser clean?

2. All LEDs flash at the same time.

• Contact the After-Sales Service.

3. The appliance is too noisy.

INSTRUCTIONS FOR USE

- Is the appliance perfectly horizontal?
- Is the appliance in contact with other furniture or objects that may cause vibrations?
- Has the packaging been removed from under the appliance?

Note: Gurgling noises from the refrigerating circuit after the compressor cuts out are perfectly normal.

4. All LEDs are off and the product is not working.

- Is there a power failure?
- Is the plug properly inserted in the socket?
- Is the electric cable intact?

5. All LEDs are off and the product is working.

- Contact the After-Sales Service.

6. The compressor runs continuously.

- Have hot foods been put in the appliance?
- Has the appliance lid been left open for a long time?
- Is the appliance placed in a very warm room or near heat sources?
- Has the fast freeze function been activated? (all Green LEDs ON)

7. Too much ice on the upper edge.

- Are the defrost water drainage plugs correctly positioned?
- Is the appliance lid properly closed?
- Is the appliance lid seal damaged or deformed? (See chapter "Installation")
- Have the 4 protection pieces been removed? (See chapter "Installation")

8. Formation of condensate on the external walls of the appliance.

- It is normal for condensation to form under certain atmospheric conditions (humidity above 85%) or if the appliance is located in a damp or poorly ventilated room. The performance of the appliance is in no way affected.

9. The layer of ice on the internal walls of the appliance is not uniform.

- This phenomenon is quite normal.

AFTER-SALES SERVICE

Before contacting Cylinda service center:








- 1.** See if you can solve the problem yourself.
- 2.** Switch the appliance on again to see if the problem has been solved. If it has not, disconnect the appliance from the power supply and wait for about an hour before switching on again.
- 3.** If the problem persists after this course of action, contact please contact Cylinda service center.

Specify:

- the nature of the fault
- the model
- the service number (the number after the word SERVICE on the rating plate on the rear of the appliance)
- your full address
- your telephone number and area code.

SERVICE 0000 000 00000





NO

Service: Kontakt butikken der du kjøpte produktet så de kan henvise deg til lokal service

Oppgi: Produkttype, Serienummer, Kjøpsdato, Problembeskrivelse, Navn og adresse, Telefonnummer

DK

Service: Kontakt butikken hvor købet blev foretaget og få info om service kontakt

Nødvendig information: Model navn, Serienummer (står på typeskiltet), Kjøpsdato, Beskrivelse af problemet, Navn og adresse, Telefonnummer

FI

Huolto: Ota yhteyttä myymälään, josta ostit tuotteen, niin saat lisätietoja lähimmästä huoltoliikkeestä

Tarvittavat tiedot: Mallinnumero, Sarjanumero, Ostopäivä, Ongelman kuvaus, Nimi ja osoite, Puhelinnumero

SE

Service: Vi har service i hela Sverige. Besök www.cylinda.se
Ring 0771-25 25 00
(endast lokaltaxa)

Uppge: Maskintyp, serienummer, inköpsdatum, problembeskrivning, namn och adress, ditt telefonnummer

Kontakta oss:
www.cylinda.se

UK

Service: Nationwide service in Sweden
Visit www.cylinda.se
Call 0771-25 25 00

Declare: Model code, Serial number, Purchase date, Problem description, Name and address, Phone number

Contact us:
www.cylinda.se

Cylinda
är efter år



400011375454/B