



TORKGUIDE

Denna instruktion gäller även för maskiner med värmepump.

1 Sortera plaggen

Sortera plaggen efter material och hur smutsiga de är. Observera symbolerna på tvättetiketterna. Stäng dragkedjor, hakar och knappar.

 Symbolen betyder att materialet tål torktumling.

 Symbolen betyder att materialet inte tål torktumling.

Torktumla inte heller...

material märkta "Torkas ej i närheten av värme", plagg som kemtvättats hemma, skumplast, glasfibermaterial, ylle.




2 Slå på strömbrytaren På/Av (ON/OFF)

3 Öppna torktumlarens lucka och lägg intvätten

Se till att trumman är tom innan du gör detta.

4 Välj torkprogram

Vrid programväljarvredet till önskat torkprogram. Valt program indikeras på displayen. Max. last är 6 kg (se programtabellen i bruksanvisningen).

	Full last
	Medellast
	Liten last



5 Välj programinställning.

Programinställningar kan endast göras för vissa program. Se kapitlet: INSTÄLLNINGAR (endast ägaren/distributören av apparaten får ändra inställningarna).

6 Stäng luckan och tryck på knappen START/STOP.

Förväntad torktid, i timmar och minuter, visas på displayen.

7 Programslut

Öppna luckan och ta ut tvätten ur torktumlaren. Rengör filtren. Se kapitlet "RENGÖRING OCH UNDERHÅLL". Stäng luckan. Sätt av strömbrytaren. Dra ut strömsladden ur eluttaget.

Rengöra nätfiltret i luckan


Skrapa försiktigt av luddet från filtret (fi ber och trådar).



Tömma kondensvattenbehållaren

(Bortse från denna varning om du har dragit utloppsslangen för kondensvatten till ett avlopp, ett vattenlås eller en vask.)

Dra ut kondensbehållaren från torktumlaren och vänd den över ett handfat eller annan lämplig behållare.





Feldisplay

Om ett fel visas på displayen, se kapitlet FEL ... VAD GÖR JAG ...?

Säkerhetsföreskrifter

 Maskinen är endast avsedd för torkning av vattentvättade textilier.

 Maskinen är inte avsedd att användas av personer (även barn) som är fysiskt eller psykiskt handikappade eller saknar erfarenhet och kunskap. Sådana personer måste få instruktion av den person som har ansvaret för deras säkerhet, hur maskinen ska användas. Barn måste övervakas så att de inte leker med maskinen.

 Under pågående program är torktumlarens baksida mycket varm. Låt maskinen svalna helt innan baksidan vidrörs.

WARNING! Textilier som tas ut efter avbrutet program kan vara mycket varma.

 Vid rengöring får maskinen inte överspolas med vatten.

DRYING GUIDE

These instructions also apply to machines with a heat pump.

1 Sort the laundry.
Sort the fabrics
Sort the fabric by type and by how heavily soiled the laundry is.
Observe the drying symbols on the laundry labels.
Close the zippers, hook-and-loop fasteners and buttons.

This symbol means that the material is suitable for tumble-drying.
 This symbol means that the material is not suitable for tumble-drying.

And do not tumble-dry...
material labelled "Do not dry near heat", garments that have been dry-cleaned at home, foam plastic, fibreglass material, wool.

2 Switch on the main ON/OFF switch.

3 Open the dryer door and insert the laundry.
Before doing so, make sure the drum is empty.

4 Choose the drying program.
Turn the program selector knob to the desired drying program.
Selected program will be indicated on the display unit.
The maximum load is 6 kg (see the Program table in the instructions for use).

<input type="radio"/>	Full load
<input type="radio"/>	Partial load
<input type="radio"/>	Small load



5 Choose the program setting.
Program settings can only be set for certain programs.
See chapter: SETTINGS (only appliance owner/distributor may change the settings).

6 Close the dryer door and press the START/STOP button.
Anticipated drying time, in hours and minutes, will be indicated on the display.

7 End of program
Open the door and remove the laundry from the dryer.
Clean the filters, See chapter "CLEANING AND MAINTENANCE".
Close the door.
Switch off the main on/off switch.
Remove the plug from the power outlet.

Cleaning the door net filter in the door
Gently scrape the filter to remove the lint lining (fibres and threads).

Emptying the condensate tank
(Disregard this warning if you fed the condensate discharge hose into a drain, siphon, or a sink.)
Pull out the condensate tank from the dryer, then turn it upside down over a washbasin, sink, or any suitably sized vessel.

Error display
If an error appears on the display unit, see chapter ERRORS ... WHAT TO DO ...?

Safety precautions

- This machine is only designed for drying water-washed items.
- The machine is not designed to be used by persons (even children) that are physically or mentally handicapped or lack experience and knowledge. Such persons must receive instruction in how to use the machine from the person responsible for their safety. Children must be watched to ensure they do not play with the machine.
- When the tumble dryer is operating, the back of the tumble dryer will get very hot. Leave the machine to cool completely before touching the back.
CAUTION! Items removed from a stopped programme may be very warm.
- The machine must not be rinsed down with water when cleaning.