

bruksanvisning



Calypso
F 150K, F 160K, F 170K

Cylinda
år efter år

Bästa kund!

Tack för att du har valt denna förstklassiga köksfläkt tillverkad av Cylinda. Läs igenom denna bruksanvisning noga. Här finns viktig information som hjälper dig installera och använda köksfläkten korrekt, vilket i sin tur ger pålitlig drift i lång tid framöver.

Symbolerna som används i bruksanvisningen betyder följande:



Viktig information om korrekt användning
av köksfläkten och om din säkerhet.



Modell ansluten till ventilationsskanal



Miljöinformation



Modell med kolfilter



Läs igenom denna bruksanvisning noga innan du börjar använda köksfläkten!

Denna bruksanvisning gäller följande produkter:

Calypso	E 90 043 65, E 90 043 66, E 90 043 67
F 150K	E 900 44 26
F 160K	E 900 44 27
F 170K	E 900 44 28

Kåpans utseende kan skilja sig från illustrationerna i bruksanvisningen. Anvisningarna för användning, underhåll och installation är dock desamma för samtliga modeller. Följ noga anvisningarna. Vi frånsäger oss allt ansvar för eventuella problem, skador eller bränder till följd av att denna bruksanvisning inte har följts. Köksfläkten är endast avsedd för användning i privata hushåll.

- ! Spara denna bruksanvisning för framtida användning. Kom ihåg att låta bruksanvisningen medfölja köksfläkten i händelse av försäljning, överlätelse eller flyttning.
- ! Läs noga igenom anvisningarna. De innehåller viktig information om installation, användning och säkerhet.
- ! Utför inte elektriska eller mekaniska ändringar på produkten eller utsuget.

Observera: Delarna märkta med symbolen "(*)" är valfria tillbehör som endast ingår i leveransen av vissa modeller eller är delar som kan köpas till och inte ingår i leveransen.

Se sidan 6 för teknisk ritning till din produkt.

Före installation



VAR FÖRSIKTIG WARNING!

Anslut inte köksfläkten till elnätet förrän installation har slutförts.

Bryt strömmen till köksfläkten före all form av rengöring eller underhåll genom att dra ur stickkontakten eller stänga av huvudbrytaren.

Bär alltid arbetshandskar vid installation och underhåll.

Denna köksfläkt är inte avsedd för användning av barn eller personer med nedsatt fysisk eller psykisk funktionsförmåga, eller som saknar erfarenhet och kunskap, såvida inte de övervakas eller har instruerats i användningen av köksfläkten av en person som ansvarar för deras säkerhet.

Denna köksfläkt är avsedd att användas av vuxna. Barn bör hållas under uppsikt så att de inte leker med köksfläkten.

Använd aldrig kåpan utan korrekt monterat galler!

Kåpan får ALDRIG användas som avställnings-/stödyta om det inte anges särskilt. Lokalen där köksfläkten är installerad måste vara väl ventilerad om köksfläkten används tillsammans med spis och annan utrustning som drivs av gas eller annat bränsle.

Köksfläktens ventilationskanal får inte vara anslutet till en ventilationssystem som används för annat ändamål, t.ex. skorstenksanal eller röksanal.

Undvik öppen eld och flambering under spiskåpan.

Oppen eld förstör filtren och utgör en brandrisk och måste därför undvikas under alla omständigheter.

Mat som tillagas i matfett ska övervakas konstant så att matfettet inte överhettas och börjar brinna.

Delar av kåpan kan bli varma vid användning av spisen.

Följ alltid myndigheternas gällande tekniska föreskrifter och säkerhetsföreskrifter för utsläpp av förorenad luft.

Kåpan måste rengöras regelbundet på både in- och utsidan (MINST EN GÅNG I MÅNADEN).

Rengöringen ska utföras enligt underhållsanvisningarna i dena bruksanvisning. Underlättelse att följa anvisningarna för ren-göring av kåpan och filtren kan medföra brandrisk.

Använd inte köksfläkten eller lämna den inte utan uppsikt om lampan inte är korrekt monterad. Annars finns det risk för elek-triska stötar.

Vi frånsäger oss allt ansvar för fel, skador och bränder orsakade av köksfläkten till följd av att bruksanvisningen inte har följts.

Denna köksfläkt är märkt i enlighet med EU:s direktiv 2002/96/EG om insamling och återvinning av elektriska och elektroniska produkter (WEEE). Genom att kassera köksfläkten korrekt förhindrar du eventuella negativa konsekvenser för miljön och människors hälsa, som annars kan uppstå vid felaktig avfallshan-tering av denna produkt.










Symbolen på produkten, eller i dokumenten som medföljer produkten, betyder att denna produkt inte får slängas i de vanliga hushållssoporna utan ska lämnas in på en återvinningsstation för elektriska och elektroniska produkter. Kasseringen måste ske i enlighet med gällande föreskrifter för avfallshantering.

Kontakta kommunen eller återförsäljaren för ytterligare information om insamling och återvinning av denna produkt.


Härmed försäkrar tillverkaren att denna produkt överensstämmer med följande EU-direktiv:

- lågspänningsdirektivet 2006/95/EG
- direktivet om elektromagnetisk kompatibilitet 2004/108/EG







7




8




9




10




11




12




13



14



15



16

Minsta tillåtna avstånd från spishällen upp till köksfläktens nedersta del är 50 cm vid elspis och 65 cm vid gasspis eller kombinerad gas- och elspis. Om installationsanvisningarna för en gasspis anger ett större avstånd gäller det större avståndet.



ELANSLUTNING

Kontrollera att nätspänningen överensstämmer med den angivna spänningen på köksfläktens typskylt. Om köksfläkten är försedd med en stickkontakt ska den anslutas till ett eluttag som uppfyller gällande föreskrifter och som är lättåtkomligt. Om köksfläkten inte är försedd med en stickkontakt (anslutning direkt till elnätet), eller om eluttaget är svåråtkomligt efter installationen av köksfläkten, ska det installeras en tvåpolig brytare som fungerar som överströmsskydd och bryter strömmen i händelse av att gränsvärdena överskrids. Brytaren ska installeras i enlighet med anvisningarna.

Varning! Kontrollera alltid att huvudkabeln är korrekt monterad innan du ansluter köksfläkten till elnätet och kontrollerar dess funktion.

Köksfläkten är försedd med en speciellkabel. Om kabeln är skadad, ska du skaffa en ny från vår tekniska avdelning.

Expansionspluggar medföljer och med dem kan köksfläkten fästas i de flesta typer av vägg/tak. Dock bör en behörig installatör kontrollera att väggen/taket tål upphängning av en köksfläkt och klarar dess vikt. Kaka inte in eller foga köksfläkten mot väggen med cementbruk eller silikon. Endast utanpåliggande montering.

Denna köksfläkt är avsedd att anslutas till ventilationskanal eller användas med kolfILTER (återcirkulation). Modellerna utan fläktmotor kan endast fungera om de är anslutna till en ventilationskanal och måste anslutas till ett externt utsug (ingår ej i leveransen).

Anslutningsanvisning medföljer det externa utsuget.

Installation

Montering

Användning

Modell ansluten till ventilationskanal

På modeller anslutna till ventilationskanal leds osen från spisen ut i det fria via ett särskilt rör anslutet ovanpå kåpan med en fläns.

Observera! Utblåsröret ingår inte i leveransen utan måste köpas separat.

Utblåsrörets diameter måste vara densamma som flänsens. När utblåsröret dras horisontellt måste det ha en lätt lutning (ca 10°) uppåt för att luften lätt ska ledas ut ur rummet. Observera! Om köksfläkten är försedd med ett aktivt kolfilter måste det tas bort.

Anslut köksfläkten till ventilationshålet i väggen med en anslutningsfläns med en diameter som passar luftutloppet.

Rör och ventilationshål i väggen med mindre diameter försämrar fläktens prestanda och ökar bullret avsevärt.

Vi frånsäger oss allt ansvar för problem och fel som uppstår vid användning av felaktiga diametrar.


- !** **Använd kortast möjliga kanal.**
- !** **Använd en kanal med så få böjar som möjligt (maximal vinkel på böj: 90°).**
- !** **Undvik drastiska ändringar av kanalens tvärsnitt.**
- !** **Använd en kanal som är så slät som möjligt på insidan.**
- !** **Kanalen måste vara tillverkad av certifierat material.**

Modell med kolfilter

Den här modellen suger in luften från köket, filtrerar den och skickar sedan ut luften i köket igen. För att köksfläkten ska fungera korrekt måste ett filter (eller flera filter) installeras. Filtnet innehåller aktivt kol som renar luften och kan köpas hos närmaste återförsäljare. Filtnet filtrerar bort fett och os från luften innan den skickas tillbaka ut i köket via gallret upp till.

Drift

Köksfläkten styrs via manöverpanelen. Manöverpanelens utseende varierar beroende på vilken modell du har köpt.



1. Diod (finns endast på vissa modeller) – lyser om köksfläkten är igång.
2. Stänger av köksfläkten oavsett hastighet.
3. Hastighetsinställningar 1 – låg hastighet, 2 – medelhastighet, 3 – hög hastighet.
4. Knapp för tändning/släckning av lampor.

OBSERVERA! Före all form av underhåll ska strömmen till köksfläkten brytas via huvudbrytaren och säkringen ska tas ur. Om köksfläkten är ansluten till elnätet via stickkontakt och eluttag måste kontakten dras ur uttaget.

Rengör spiskåpan regelbundet (minst lika ofta som du rengör fettfiltren) både in- och utvärdigt. Använd en fuktad mjuk trasa med lite neutralt rengöringsmedel. Använd inte repande medel. **ANVÄND INTE ALKOHOL**

VARNING: Om spiskåpan inte rengörs enligt anvisningarna och fettfiltren inte byts ut finns det risk för brand.

Därför rekommenderar vi att du följer dessa anvisningar.

Tillverkaren frånsäger sig allt ansvar för skador på motorn eller brandskador orsakade av bristfälligt underhåll eller underlättelse att följa ovanstående säkerhetsåtgärder.

Fångar in fettpartiklar från matlagningen.

Fettfiltret måste rengöras en gång i månaden (eller när indikeringslampan för mättat filter tänds – om din fläktmodell är försedd med denna funktion). Diska filtret för hand eller i diskmaskin (med låg vattentemperatur och kort diskcykel) och använd endast milt diskmedel.

Om filtret maskindiskas kan det bli lätt missfärgat, men det påverkar inte dess filtreringsförmåga.

Lossa filtret genom att dra i snäpplåset.

Underhåll

Rengöring

Fettfilter

Cirkulationsläge

Med denna inställning släpps filtrerad luft tillbaka in i rummet genom öppningar i kåpan. I detta läge måste kolfilter användas, se instruktion 16 på sida 8:

1. Fläkten är inställt på cirkulations läge (skruven måste lossas).
2. Följande inställningar måste vara utförda för cirkulationsläget:
 - Ta bort det nedre metallhölet genom att skifta plastreglaget.
 - Öppna upp fläktens främre luftöppning genom att ställa reglaget i nedersta läget.
 - Montera kolfiltret.
 - Montera tillbaka det nedre metallhölet.
 - Anslut fläkten till vägguttaget.

Byte av lampor

Calypsomodellerna är försedda med 2 x 20 W-halogenlampor. Byte av lampor: se sidan 7, figurerna 10–12. Ta bort kåpan och tryck sedan ner lampan uppifrån. Ta emot lampan underifrån med den andra handen. Koppla ur hela enheten och byt ut den mot en ny. Upprepa momenten i omvänt ordningsföljd för att sätta i den nya lampan.

Modellerna i F-serien är försedda med en 28 W-halogenlampa. Byte av lampa: se sidan 8, figurerna 13–15. Ta bort aluminiumfiltren. Ta bort den trasiga lampan och sätt i en ny. Använd en bit tyg eller hushållspapper för att hålla i lampan. Sätt tillbaka aluminiumfiltren.

VIKTIGT! Använd alltid samma typ av lampa som installerats av tillverkaren. Om du är osäker på vilken typ av lampa det ska vara, kan du kontakta närmaste återförsäljare av Cylinda.

Dear Customer,

Thank you for choosing this high quality cooker hood made by Cylinda. Please read this manual carefully. In it you will find important information that will help you to install and use this appliance in a proper manner resulting in long-term reliable operation of the device.

Symbols appearing in these instructions have the following meaning:



Important information concerning proper operation of the appliance and your personal safety.



Ducting version



Information on how to protect the environment.



Filter version



Before using the appliance, please carefully read this manual!

This manual applies to the following products:

Calypso	E 90 043 65, E 90 043 66, E 90 043 67
F 150K	E 900 44 26
F 160K	E 900 44 27
F 170K	E 900 44 28

The hood can look different to that illustrated in the drawings in this booklet. The instructions for use, maintenance and installation, however, remain the same.

Closely follow the instructions set out in this manual. All responsibility, for any eventual inconveniences, damages or fires caused by not complying with the instructions in this manual, is declined. The extractor hood has been designed exclusively for domestic use.

- !** **It is important to conserve this booklet for reference at any moment. In case of sale, cession or move, make sure it is together with the product.**
- !** **Read the instructions carefully: there is important information about installation, use and safety.**
- !** **Do not carry out electrical or mechanical variations on the product or on the discharge conduits.**

Note: the elements marked with the symbol “(*)” are optional accessories supplied only with some models or elements to purchase, not supplied.

For technical drawings please turn to page 6 to find your product

Before the installation



CAUTION

WARNING!

Do not connect the appliance to the mains until the installation is fully complete.

Before any cleaning or maintenance operation, disconnect the device from the power supply by removing the plug or switching off the power circuit.

Always wear work gloves for all installation and maintenance operations.

The appliance is not intended for use by children or persons with impaired physical, sensorial or mental abilities, or if lacking in experience or knowledge, unless they are under supervision or have been trained in the use of the appliance by a person responsible for their safety.

This appliance is designed to be operated by adults, children should be monitored to ensure that they do not play with the appliance.

Never use the hood without effectively mounted grating!

The hood must NEVER be used as a support surface unless specifically indicated.

The premises where the appliance is installed must be sufficiently ventilated when the kitchen hood is used together with other gas combustion devices or other fuels.

The ducting system for this appliance must not be connected to any existing ventilation system which is being used for any other purpose such as discharging exhaust fumes from appliances burning gas or other fuels.

The flaming of foods beneath the hood itself is strictly prohibited.

The use of exposed flames is detrimental to the filters and may cause a fire risk, and

must therefore be avoided in all circumstances.

Any frying must be done with care in order to make sure that the oil does not overheat and ignite.

Accessible parts of the hood may become hot when used with the cooking appliance.

With regards to the technical and safety measures to be adopted for fume discharging it is important to closely follow the regulations provided by the local authorities.

The hood must be regularly cleaned both on the inside and outside (AT LEAST ONCE A MONTH).

This must be completed in accordance with the maintenance instructions provided in this manual. Failure to follow the instructions provided in this user guide regarding the cleaning of the hood and filters will lead to the risk of fires.

Do not use or leave the hood without the lamp correctly mounted due to the possible risk of electric shocks.

We will not accept any responsibility for any faults, damage or fires caused to the appliance as a result of the non-observance of the instructions included in this manual.

This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.









The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal.


For further detailed information regarding the process, collection and recycling of this product, please contact the appropriate department of your local authorities or the local department for household waste or the shop where you purchased this product.

The manufacturer hereby declares that the appliance fulfills the requirements of the following European Directives:


- Low Voltage Directive 2006/95/EC
- Electromagnetic Compatibility Directive 2004/108/EC

This device is marked with mark and the appropriate declaration of conformity is available to the market supervising authorities.









7




8




11







13



14



15



16

The minimum distance between the supporting surface for the cooking equipment on the hob and the lowest part of the range hood must not be less than 50cm from electric cookers and 65cm from gas or mixed cookers. If the instructions for installation for the gas hob specify a greater distance, this must be adhered to.



ELECTRICAL CONNECTION

The mains power supply must correspond to the rating indicated on the plate located inside the hood. If provided with a plug connect the hood to a socket which is in compliance with current regulations and located in an easily accessible area. If it is not fitted with a plug (direct mains connection) or if after installation the plug is not located in an accessible area, apply a double pole switch in accordance with standards which assures the complete disconnection of the mains under conditions relating to over-current category III, in accordance with installation instructions.

Warning! Before re-connecting the hood circuit to the mains supply and checking the efficient function, always check that the mains cable is correctly assembled.

The hood is provided with a special power cable; if the cable is damaged, request a new one from Technical Service.

Expansion wall plugs are provided to secure the hood to most types of walls/ceilings. However, a qualified technician must verify suitability of the materials in accordance with the type of wall/ceiling. The wall/ceiling must be strong enough to take the weight of the hood. Do not tile, grout or silicone this appliance to the wall. Surface mounting only.

This appliance is designed to be used either for exhausting or filter version. The models with no suction motor only operate in ducting mode, and must be connected to an external suction device (not supplied).

The connecting instructions are supplied with the peripheral suction unit.

Installation

Mounting

Use

Ducting version

In this case the fumes are conveyed outside of the building by means of a special pipe connected with the connection ring located on top of the hood.

Attention! The exhausting pipe is not supplied and must be purchased separately.

Diameter of the exhausting pipe must be equal to that of the connection ring. In the horizontal runs the exhausting pipe must be slightly slanted (about 10°) and directed upwards to vent the air easily from the room to the outside. Attention! If the hood is supplied with active charcoal filter, then it must be removed.

Connect the hood and discharge holes on the walls with a diameter equivalent to the air outlet (connection flange).

Using the tubes and discharge holes on walls with smaller dimensions will cause a diminution of the suction performance and a drastic increase in noise.

Any responsibility in the matter is therefore declined.


- !** **Use a duct of the minimum indispensable length.**
- !** **Use a duct with as few elbows as possible (maximum elbow angle: 90°).**
- !** **Avoid drastic changes in the duct cross-section.**
- !** **Use a duct with an as smooth as possible inside.**
- !** **The duct must be made of certified material.**

Filter version

In this work mode the hood extracts and cleans the air from the kitchen and after that the air is sent back to the room. In order for the device to work properly an additional filter (or filters) must be installed. The filter utilizes active charcoal for air purification and can be obtained from your nearest retailer. The filter removes the grease and smells from the extracted air before sending it back into the room through the upper outlet grid.

Operation

The cooker hood is operated by mechanical buttons.



1. Diode (available in selected models only) - indicates if the appliance is in operation.
2. Switches off the appliance from any speed.
3. Available speed settings, 1 - low speed, 2 - medium speed, 3 - high speed.
4. Light on/off switch.

ATTENTION! Before performing any maintenance operation, disconnect the hood from the electrical supply by switching off at the connector and removing the connector fuse.

Alternatively if the appliance has been connected through a plug and socket, then the plug must be removed from the socket.

The cooker hood should be cleaned regularly (at least with the same frequency with which you carry out maintenance of the fat filters) internally and externally. Clean using the cloth dampened with neutral liquid detergent. Do not use abrasive products. **DO NOT USE ALCOHOL!**

WARNING: Failure to carry out the basic cleaning recommendations of the cooker hood and replacement of the filters may cause fire risks.

Therefore, we recommend observing these instructions.

The manufacturer declines all responsibility for any damage to the motor or any fire damage linked to inappropriate maintenance or failure to observe the above safety recommendations.

Maintenance

Cleaning

Grease filter

Traps cooking grease particles.

This must be cleaned once a month using non aggressive detergents, either by hand or in the dishwasher, which must be set to a low temperature and a short cycle.

When washed in a dishwasher, the grease filter may discolour slightly, but this does not affect its filtering ability.

To remove the grease filter, pull the spring release handle

Re-circulation mode

In this option filtered air returns to the room through openings in the front of the hood. In this setting it is necessary to install the carbon filter. Refer to the drawing 16 on page 18:

1. The cooker hood is implicitly set to the re-circulation mode (the bolt is screwed up).
2. The following adjustment must be made for the re-circulation mode:
 - By shifting the plastic stoppers, demount the appliance's bottom metal cover.
 - By tilting the clack into the bottom limit position, open the air output in the appliance upper front section.
 - Remount the appliance's bottom metal cover.
 - Place the fat retention (or also the carbon) filter.
 - Plug the supply cable into the wall outlet

Replacing lamps

The Calypso models are equipped with 2 x 20W halogen lights. To replace the lamps refer to the drawings 10 through 12 on page 7. Remove the decorative bottom cover then using your hand push the lighting downwards. Grab the lighting with your other hand. Disconnect the complete element and replace it with a new part. proceed in reverse order to finish the replacement of the lighting.



The F-series models are equipped with a single 28W halogen bulb. To replace the bulb refer to the drawings 13 through 15 on page 8. Remove the aluminium filters, replace the bulb using a piece of cloth or paper and reinstall the aluminium filters.



IMPORTANT!! Always use the lighting of the same type as installed by the manufacturer. If you are not sure which part to use contact your nearest Cylinda dealer.

Namn**Name**

Calypso K 50, 60, 70	24
F 150K, F 160K	25
F 170K	26

Tekniska ritningar
Technical drawings







service uppge

- Vi har service i hela landet
- Gå in på www.cylinda.se eller
- Ring 0771-25 25 00 (endast lokaltaxa)

- Maskintyp
- Serienummer
- Inköpsdatum
- Problembeskrivning
- Namn och adress
- Ditt telefonnummer

Våra tekniker är specialutbildade på Cylindaproducter och vi använder bara originalreservdelar.

Elektroskandia Sverige AB, Cylinda, 191 83 Sollentuna

Cylinda
år efter år